

<b>PRODUCT LINE</b>	Colourplus Ultra Pave																		
<b>DESCRIPTION</b>	Colourplus Ultra Pave is a tough, hard wearing Polyurethane Copolymer coating for all concrete floors.																		
<b>TYPICAL USES</b>	May be used on suitably prepared: <ul style="list-style-type: none"><li>• Concrete floors</li><li>• Timber floors and decks</li><li>• Fibrolite floors</li></ul>																		
<b>PHYSICAL PROPERTIES</b>	<table><tr><td>Binder Type</td><td>Modified Urethane</td></tr><tr><td>Thinning</td><td>Mineral turpentine</td></tr><tr><td>Colour</td><td>White and tinted colours</td></tr><tr><td>Finish</td><td>Satin</td></tr><tr><td>Dry time</td><td>1 hour at 20°C</td></tr><tr><td>Recoat time</td><td>4 hours at 20°C</td></tr><tr><td>Number of coats</td><td>2 or 3</td></tr><tr><td>Theoretical Coverage</td><td>10-14m<sup>2</sup> per litre at 30 microns D.F.T</td></tr><tr><td>Clean up</td><td>Mineral turpentine</td></tr></table>	Binder Type	Modified Urethane	Thinning	Mineral turpentine	Colour	White and tinted colours	Finish	Satin	Dry time	1 hour at 20°C	Recoat time	4 hours at 20°C	Number of coats	2 or 3	Theoretical Coverage	10-14m <sup>2</sup> per litre at 30 microns D.F.T	Clean up	Mineral turpentine
Binder Type	Modified Urethane																		
Thinning	Mineral turpentine																		
Colour	White and tinted colours																		
Finish	Satin																		
Dry time	1 hour at 20°C																		
Recoat time	4 hours at 20°C																		
Number of coats	2 or 3																		
Theoretical Coverage	10-14m <sup>2</sup> per litre at 30 microns D.F.T																		
Clean up	Mineral turpentine																		
<b>SURFACE PREP</b>	Ensure surfaces are free from loose or flaky paint. Wash surfaces with Colourplus Blue Wash prior to painting to remove oil, grease, dirt, and other contaminants. Where there are areas of mould, treat with Colourplus Green Clean.																		
<b>APPLICATION</b>	Colourplus Ultra Pave may be applied by brush, roller or spray.  <b>Concrete</b> <ol style="list-style-type: none"><li>1. Ensure concrete is fully cured and contains less than 7% moisture.</li><li>2. Apply Concrete Etch to all bare concrete surfaces.</li><li>3. Apply 2 or 3 coats of Ultra Pave , allowing overnight drying between coats, with the first coat thinned 15% with mineral turpentine.</li></ol> <p><i>Note: Where ideal preparation is not possible, apply 1 coat of Liquid Vinyl . Allow 4 hours before over coating with Ultra Pave.</i></p> <b>Wood</b> <ol style="list-style-type: none"><li>1. For bare timber apply 1 coat of Proprime .</li><li>2. Apply 2 coats of Ultra Pave, allowing 4 hours at 20°C between coats.</li></ol> <b>Repaints</b> <ol style="list-style-type: none"><li>1. Sand back to a dull finish using 80 grit paper.</li><li>2. Ensure surface is clean, dry and free from grease, dirt and mould.</li><li>3. Apply 2 coats of Ultra Pave, allowing 4 hours at 20°C between coats.</li></ol>																		

**PERFORMANCE  
& LIMITATIONS**

Performance

- Excellent adhesion
- High abrasion resistance
- Suitable for light foot traffic areas and domestic garages
- Good chemical resistance
- Easy to clean

Limitations

- Unsuitable for heavy traffic areas
- Resistance to hot tyres may vary depending on concrete preparation and adhesion to concrete surface

**HEALTH & SAFETY**

Solvent Containing

Colourplus Ultra Pave is lead free but contains solvents. Do not expose containers to naked flame or high temperature heating equipment. It is recommended that a barrier cream be used for hands and that when spraying, safety glasses or a face mask be worn.

Transport

UN No.	:	1263
Class	:	3
Hazchem	:	3(Y)

Storage

Avoid freezing or temperatures in excess of 50°C.