



ULTRA PREMIUM

Ultracare Low Sheen

Water Based Enamel
Technical Data Sheet UP336

PRODUCT LINE	Ultra Premium Ultracare Low Sheen	
DESCRIPTION	<p>Ultra Premium Ultracare Low Sheen is the ultimate finish for interior walls and ceilings. It's low sheen water based enamel and has been formulated to provide a totally washable finish with excellent stain resistant properties. Ultra Premium Ultracare is fast drying, non yellowing, has a very low odor and cleans up in water.</p> <p>Ultra Premium Ultracare Low Sheen comes with a 15 year guarantee</p> <p>Interior and Exterior use</p>	
TYPICAL USES	For broadwall areas where a hard wearing finish is required. Also excellent for timber doors, architraves, skirting's, window frames and exterior trims.	
PHYSICAL PROPERTIES	Binder type	Unique cross linking acrylic
	Solvent	Water
	Colour	White and bases
	Finish	Low sheen - 5% gloss
	Dry Time	1 hour at 20°C
	Recoat Time	2 - 4 hours at 20°C
	Number of Coats	2
	Theoretical Coverage	12m ² per litre
	Recommended Film Thickness	100 microns per coat W.F.T
	Thinning and Clean Up	Water. (In hot conditions can be thinned up to 5% with Protec Hot Weather Thinners)
SURFACE PREP	<p>Ensure surfaces are free from loose or flaky paint. Wash surfaces with Colourplus Sugar Soap prior to painting to remove oil, grease, dirt, and other contaminants. Where there are areas of mould, treat with Colourplus Green Clean.</p> <p>Old enamels will require fine sanding to a uniform dull finish.</p>	
APPLICATION	<p>Ultra Premium Ultracare may be applied by synthetic brush, roller or spray. Airless Spray - a 415 or 515 tip is recommended. Roller Sleeve - a 6mm nap micro fibre roller is recommended.</p> <p>Because of the quick drying nature of the Ultracare, in hot conditions it may be necessary to thin up to 5% with Protec Hot Weather Thinners.</p> <p>When rolling walls that are highlighted by natural lighting from large window areas, you will need to "lay off" with the roller in one direction after applying the paint. This should be done in one continuous operation from one end of the wall to the other without stopping. Always ensure a wet edge is maintained.</p> <p>For large areas two applicators may be required, one to lay on the paint and the other to "lay off"</p>	

Timber, Particle Board, Customwood

1. Prime with Permaseal.
2. Apply 2 coats of Ultra Premium Ultracare water based enamel in required colour.

Gib Board, Fibrous Plaster

1. Apply 1 coat of Designa Acrylic Sealer Undercoat
2. Lightly sand and dust off
3. Apply 2 coats of Ultra Premium Ultracare water based enamel in required colour

Previously Painted Surfaces

1. Remove any flaking paint off the surface and sand to a smooth finish
2. Prime any areas of bare timber with Permaseal
3. Old enamels require washing down with Colourplus Sugar Soap and fine sanding to a dull finish
4. Apply 2 coats of Ultra Premium Ultracare water based enamel in required colour

PERFORMANCE & LIMITATIONS

Performance

- Ultimate hard wearing wall finish
- Can be used where traditional oil based enamels are used
- Non yellowing
- Easy application properties with excellent flow and leveling
- Excellent durability in high service areas

Limitations

- Should not be applied if temperatures are below 10°C
- Dry time may be impeded if the relative humidity is high
- Ensure that the correct primer/sealer is used
- Allow putty and gap fillers to fully dry and prime putty before applying top coat
- After applying Ultra Premium Ultracare water based enamel 12-48 hours should be allowed before the area becomes fully serviceable

HEALTH & SAFETY

Waterborne

Ultra Premium Ultracare Low Sheen is a water reducible non toxic coating. It is non flammable and requires no specific handling. We recommend the use of a barrier cream for hands when applying.

Transport

UN No.	:	N/A
Class	:	N/A
Hazchem	:	N/A

Storage

Avoid freezing or temperatures in excess of 50°C